

NOTE:
ALL STAKES AND TIES TO BE REMOVED
BY CONTRACTOR PRIOR TO FINAL
ACCEPTANCE.


WILTPROOF IN NURSERY
PRIOR TO DELIVERY

SET WHIPS 50mm HIGHER THAN
ADJACENT FINISHED GRADE TO
ALLOW FOR SETTLEMENT

PLANTING METHOD ILLUSTRATED
APPLIES EQUALLY TO BARE ROOT,
POTTED OR B&B NURSERY STOCK

TIE TREE TO STAKES WITH
BIODEGRADABLE HEAVY DUTY
JUTE MATERIAL (BINDER TWINE)

NO. 1 SPRUCE WOOD STAKES
SECURED INTO GROUND JUST INSIDE
OF TREE PIT ON SIDE OF
PREVAILING WIND AS SHOWN



PRUNING SHALL BE LIMITED
TO DEAD OR BROKEN BRANCHES
AFTER PLANTING.
DO NOT TRIM LEADER BRANCH.

SPIRAL PLASTIC SLEEVE RODENT
GUARD MANDATORY DURING
MAINTENANCE PERIOD - OR
APPROVED EQUAL, TO REACH JUST
UNDER SURFACE OF SOIL

KEEP MULCH BACK 50mm
FROM TRUNK OF TREE

CONSTRUCT 100mm SOIL SAUCER AROUND
TREE BASE AND COVER WITH 75mm
APPROVED SHREDDED WOOD MULCH

SPECIFIED SOIL MIXTURE FIRMLY
COMPACTED TO ELIMINATE AIR
POCKETS AND PREVENT SETTLEMENT

REMOVE NURSERY POTS OR
WRAP PRIOR TO PLANTING

COMPACTED SUBGRADE

SHRUB HEIGHT SHALL BE
MEASURED FROM FINISHED
GRADE TO UPPER MAIN MASS
OF SHRUB BRANCHES

SHRUBS PLANTED IN GROUPS
SHALL BE SET IN CONTINUOUS
BEDS AS SHOWN ON PLAN

PRUNING - TO SUIT SPECIES - PRUNE
LARGE BRANCHES BY 1/3 TO REMOVE
DAMAGED OR OBJECTIONABLE BRANCHES
FOLLOWING PROPER HORTICULTURAL
PRACTICE. DO NOT PRUNE LEADERS.

MULCHING - 75mm OF APPROVED
SHREDDED WOOD MULCH

CUT AND REMOVE 1/3 OF BURLAP
FROM 1/3 OF BALL AS SHOWN. IF ROOT BALL IS POTTED REMOVE
POT COMPLETELY BEFORE PLANTING

EARTH SAUCER TO RETAIN MOISTURE
EARTH SAUCER TO BE SET LEVEL

SHRUB BASE TO BE SET LEVEL

EXCAVATE SHRUB BED TO ACCOMMODATE
NUMBER OF SHRUBS INDICATED ON DRAWING.
REMOVE ANY SUB SOIL OR RUBBISH OFF SITE
UNLESS OTHERWISE DIRECTED. SPACE SHRUBS
AS INDICATED IN PLANT LIST.

SPECIFIED SOIL MIXTURE IS TO BE
FIRMLY COMPACTED TO ELIMINATE
AIR POCKETS AND PREVENT SETTLEMENT

COMPACTED SUBGRADE

4 SHRUB PLANTING DETAIL ON SLOPES
TYPICAL INSTALLATION

NTS
ABAL P302-040505

NOTES:
1. WILTPROOF IN NURSERY PRIOR TO
DELIVERY.
2. PRUNING SHALL BE LIMITED TO
DEAD, DISEASED OR BROKEN
BRANCHES AFTER PLANTING.
MAINTAIN ORIGINAL SHAPE OF THE
TREE. DO NOT TRIM LEADER
BRANCH.
3. SET TOP OF ROOT BALL 75-100mm
HIGHER THAN ADJACENT FINISHED
GRADE TO ALLOW FOR
SETTLEMENT.

SET TREE STAKES JUST
INSIDE TREE PIT AS SHOWN

SLOPE SITUATION

FINISHED GRADE

CUT AND REMOVE TOP 1/3 OF
BURLAP FROM ROOTBALL, INCLUDING
ALL TIE ROPE AND WIRE


SCARIFY, LOOSEN, AND IRRIGATE
THE INSIDE OF THE TREE PIT
PRIOR TO PLANTING

PROVIDE 75mm SOIL MOUND AT
BASE OF PIT AS SHOWN

COMPACTED SUBGRADE

1 DECIDUOUS TREE PLANTING DETAIL
TOWN OF CALEDON STANDARD DETAIL

NTS



WET POND PLANTING STRATEGY

ADAPTED FROM THE TRCA 'STORMWATER MANAGEMENT POND
PLANTING GUIDELINES', SEPTEMBER 2007

NTS
P 301X

NOTE:
ALL STAKES, TREE WRAP, HOSES, AND
WIRES TO BE REMOVED BY CONTRACTOR
PRIOR TO FINAL ACCEPTANCE.

WILTPROOF IN NURSERY
PRIOR TO DELIVERY

PRUNING SHALL BE LIMITED
TO DEAD OR BROKEN BRANCHES
AFTER PLANTING. MAINTAIN
ORIGINAL SHAPE OF TREE.
DO NOT TRIM LEADER BRANCH.

SET TREE STAKES JUST
INSIDE TREE PIT AS SHOWN

MAINTAIN ORIGINAL GRADE OF TREE
BASE AFTER PLANTING OR SLIGHTLY
HIGHER TO SUIT SOIL CONDITIONS

FINISHED GRADE


CUT AND REMOVE TOP 1/3 OF
BURLAP FROM ROOTBALL, INCLUDING
ALL TIE ROPE AND WIRE

SCARIFY, LOOSEN, IRRIGATE AND
FERTILIZE THE INSIDE OF THE TREE PIT
PRIOR TO PLANTING

COMPACTED SUBGRADE

5 DECIDUOUS TREE PLANTING ON SLOPE DETAIL
TYPICAL INSTALLATION

NTS
ABAL P303-051021



IF CONTRACTOR ELECTS TO WRAP TREE
TRUNK, TREE TO BE WRAPPED WITH
APPROVED TREE WRAP AFTER VISUAL
INSPECTION BY LANDSCAPE ARCHITECT.
WRAP TO EXTEND FROM TOP OF ROOTBALL

TWO 2400mm LONG 50mm SQUARE
PRESSURE TREATED WOOD STAKES
SECURED INTO GROUND AS SHOWN

RODENT GUARD MANDATORY
DURING 3 YEAR MAINTENANCE PERIOD.

CONSTRUCT SOIL SAUCER 100mm DEEP,
600mm DIA. AROUND TREE BASE
AND COVER WITH 75mm APPROVED
SHREDDED WOOD MULCH

SPECIFIED SOIL MIXTURE FIRMLY
COMPACTED TO ELIMINATE AIR
POCKETS AND PREVENT SETTLEMENT.

COMPACTED SUBGRADE

NOTE:
ALL STAKES, TREE WRAP, HOSES, AND
WIRES TO BE REMOVED BY CONTRACTOR
PRIOR TO FINAL ACCEPTANCE.

TREE SHALL BE MEASURED TO
HEIGHT OF LAST YEARS GROWTH

PRUNING SHALL BE LIMITED TO DEAD
OR BROKEN BRANCHES AFTER PLANTING.
MAINTAIN ORIGINAL SHAPE OF TREE.
DO NOT TRIM LEADER BRANCH.

MAINTAIN ORIGINAL GRADE OF TREE
BASE AFTER PLANTING OR SLIGHTLY
HIGHER TO SUIT SITE SOIL CONDITIONS

SET TREE STAKES JUST
INSIDE TREE PIT, AS SHOWN.
TREE PIT TO EXTEND BEYOND THE
MAXIMUM REACH OF TREE BRANCHES.

SCARIFY, LOOSEN, IRRIGATE AND
FERTILIZE THE INSIDE OF THE TREE
PIT PRIOR TO PLANTING

COMPACTED SUBGRADE

FINISHED GRADE

SPECIFIED SOIL MIXTURE FIRMLY
COMPACTED TO ELIMINATE AIR
POCKETS AND PREVENT SETTLEMENT


CUT AND REMOVE TOP 1/3 OF
BURLAP FROM ROOTBALL, INCLUDING
ALL TIE ROPE AND WIRE

EXCAVATE AND PREPARE PLANTING
BED TO MINIMUM 500mm DEPTH
AS SPECIFIED

COMPACTED SUBGRADE

6 CONIFEROUS TREE PLANTING ON SLOPE DETAIL
TYPICAL INSTALLATION

NTS
ABAL P304-000119



PRUNING SHALL BE LIMITED
TO DEAD OR BROKEN BRANCHES
AFTER PLANTING. MAINTAIN
ORIGINAL SHAPE OF SHRUB.
DO NOT TRIM LEADER BRANCH.

DO NOT PLACE MULCH WITHIN 50MM FROM
SHRUB BASE

CONSTRUCT 100mm SOIL SAUCER
AROUND TREE BASE AND COVER
WITH 75mm APPROVED SHREDDED
WOOD MULCH OVER ENTIRE BED AREA

SPECIFIED SOIL MIXTURE FIRMLY
COMPACTED TO ELIMINATE AIR
POCKETS AND PREVENT SETTLEMENT

REMOVE NURSERY POTS OR
WRAP PRIOR TO PLANTING

COMPACTED SUBGRADE

NOTES:
1. TREE SHALL BE MEASURED TO HEIGHT
OF LAST YEARS GROWTH.
2. PRUNING SHALL BE LIMITED TO DEAD
OR BROKEN BRANCHES AFTER
PLANTING. MAINTAIN ORIGINAL
SHAPE OF TREE. DO NOT TRIM
LEADER BRANCH.
3. SET TREE 75-100mm HIGHER THAN
ADJACENT FINISHED GRADE TO
ALLOW FOR SETTLEMENT.

12 GAUGE GALVANIZED WIRE ENCLOSED IN 12mm
DIAMETER RUBBER HOSE SECURED AROUND THE
TREE TRUNK. PROVIDE WIRE TURNBUCKLE FOR
TENSION ADJUSTMENT

FINISHED GRADE

SCARIFY, LOOSEN, IRRIGATE AND
FERTILIZE THE INSIDE OF THE TREE
PIT PRIOR TO PLANTING

PROVIDE 75mm SOIL MOUND AT
BASE OF PIT AS SHOWN

COMPACTED SUBGRADE

CONIFEROUS TREE PLANTING

TOWN OF CALEDON

2 CONIFEROUS TREE PLANTING DETAIL
TOWN OF CALEDON STANDARD DETAIL

NTS

APRD. C.C. DATE: JUNE 08

2 STANDARD No. 701 NOW 801

1 STANDARD No. 1105 NOW 701

NO. REVISION

APRD. DATE

STANDARD No. 801

APRD. C.C. DATE: JUNE 08

2 STANDARD No. 1110 NOW 702

1 WEED BARRIER ADDED

NO. REVISION

APRD. DATE

STANDARD No. 802

APRD. C.C. DATE: JUNE 08

2 STANDARD No. 1110 NOW 702

1 WEED BARRIER ADDED

NO. REVISION

APRD. DATE

STANDARD No. 802

APRD. C.C. DATE: JUNE 08

2 STANDARD No. 1110 NOW 702

1 WEED BARRIER ADDED

NO. REVISION

APRD. DATE

STANDARD No. 802

APRD. C.C. DATE: JUNE 08

2 STANDARD No. 1110 NOW 702

1 WEED BARRIER ADDED

NO. REVISION

APRD. DATE

STANDARD No. 802

APRD. C.C. DATE: JUNE 08

2 STANDARD No. 1110 NOW 702

1 WEED BARRIER ADDED

NO. REVISION

APRD. DATE

STANDARD No. 802

APRD. C.C. DATE: JUNE 08

2 STANDARD No. 1110 NOW 702

1 WEED BARRIER ADDED

NO. REVISION

APRD. DATE

STANDARD No. 802

APRD. C.C. DATE: JUNE 08

2 STANDARD No. 1110 NOW 702

1 WEED BARRIER ADDED

NO. REVISION

APRD. DATE

STANDARD No. 802

APRD. C.C. DATE: JUNE 08

2 STANDARD No. 1110 NOW 702

1 WEED BARRIER ADDED

NO. REVISION

APRD. DATE

STANDARD No. 802

APRD. C.C. DATE: JUNE 08

2 STANDARD No. 1110 NOW 702

1 WEED BARRIER ADDED

NO. REVISION

APRD. DATE

STANDARD No. 802

APRD. C.C. DATE: JUNE 08

2 STANDARD No. 1110 NOW 702

1 WEED BARRIER ADDED

NO. REVISION

APRD. DATE

STANDARD No. 802

APRD. C.C. DATE: JUNE 08

2 STANDARD No. 1110 NOW 702

1 WEED BARRIER ADDED

NO. REVISION

APRD. DATE

STANDARD No. 802

APRD. C.C. DATE: JUNE 08

2 STANDARD No. 1110 NOW 702

1 WEED BARRIER ADDED

NO. REVISION

APRD. DATE

STANDARD No. 802

APRD. C.C. DATE: JUNE 08

2 STANDARD No. 1110 NOW 702

1 WEED BARRIER ADDED

NO. REVISION

APRD. DATE

STANDARD No. 802

APRD. C.C. DATE: JUNE 08

2 STANDARD No. 1110 NOW 702

1 WEED BARRIER ADDED

NO. REVISION

APRD. DATE

STANDARD No. 802

APRD. C.C. DATE: JUNE 08

2 STANDARD No. 1110 NOW 702

1 WEED BARRIER ADDED

NO. REVISION

APRD. DATE

STANDARD No. 802

APRD. C.C. DATE: JUNE 08

2 STANDARD No. 1110 NOW 702

1 WEED BARRIER ADDED

NO. REVISION

APRD. DATE

STANDARD No. 802

APRD. C.C. DATE: JUNE 08

2 STANDARD No. 1110 NOW 702

1 WEED BARRIER ADDED

NO. REVISION

APRD. DATE

STANDARD No. 802

APRD. C.C. DATE: JUNE 08

2 STANDARD No. 1110 NOW 702

1 WEED BARRIER ADDED

NO. REVISION

APRD. DATE

STANDARD No. 802

APRD. C.C. DATE: JUNE 08

2 STANDARD No. 1110 NOW 702

1 WEED BARRIER ADDED

NO. REVISION

APRD. DATE

STANDARD No. 802

APRD. C.C. DATE: JUNE 08

2 STANDARD No. 1110 NOW 702

1 WEED BARRIER ADDED

NO. REVISION

APRD. DATE

STANDARD No. 802

APRD. C.C. DATE: JUNE 08

2 STANDARD No. 1110 NOW 702

1 WEED BARRIER ADDED

NO. REVISION

APRD. DATE

STANDARD No. 802

APRD. C.C. DATE: JUNE 08

2 STANDARD No. 1110 NOW 702

1 WEED BARRIER ADDED

NO. REVISION

APRD. DATE

STANDARD No. 802

APRD. C.C. DATE: JUNE 08

2 STANDARD No. 1110 NOW 702

1 WEED BARRIER ADDED

NO. REVISION

APRD. DATE

STANDARD No. 802

APRD. C.C. DATE: JUNE 08

2 STANDARD No. 1110 NOW 702

1 WEED BARRIER ADDED

NO. REVISION

APRD. DATE

STANDARD No. 802

APRD. C.C. DATE: JUNE 0